

PB-2620


Serial number: 38000001-38999999

Last update date: 01/28/2020

TABLE OF CONTENTS

CYLINDER, PISTON, CRANKSHAFT.....	1
CRANKCASE	3
MAGNETO.....	5
AIR CLEANER, CARBURETOR.....	7
CARBURETOR.....	9
FUEL TANK.....	11
MUFFLER	13
RECOIL STARTER, PULLY	15
FAN CASE	17
THROTTLE	19
PIPE.....	21
ACCESSORIES	23


CYLINDER, PISTON, CRANKSHAFT



CYLINDER, PISTON, CRANKSHAFT

Key No.	LV (+)	Part No	Description	Qty	Standard
1		A011-001570	CRANKSHAFT,ASY	1	
2		A130-002370	CYLINDER	1	
3		V100-000860	GASKET,CYL	1	T0.5
4		V805-000210	BOLT, TORX 5	4	TB-5*20 12.9
5		P021-052780	PISTON KIT	1	
6	+	A101-000010	RING,PISTON	2	
7	+	100013-35430	PIN, PISTON	1	6*9*27.8
8	+	100015-03931	CIRCLIP, PISTON PIN	2	
9	+	V554-000020	BEARING,NEEDLE 9	1	KTV-91212EG14-B2
10	+	100014-53630	SPACER, PISTON PIN	2	
11		A190-001640	COVER,ENGINE	1	W/TPE GRIP
12		V805-000010	BOLT, TORX 5	6	TT-5*20 DG 10.9


CRANKCASE



CRANKCASE

Key No.	LV (+)	Part No	Description	Qty	Standard
1		P021-052790	CRANKCASE SET	1	
2	+	900800-36001	BEARING, BALL	1	6001
3	+	100212-42031	OILSEAL	1	ISCD 12*22*4.5
4	+	900810-36000	BEARING, BALL	1	6000
5	+	V503-000040	SEAL,OIL 10	1	ISCD 10*20*5F
6	+	V102-000300	GASKET,CRANKCASE	1	
7	+	V805-000220	BOLT, TORX 5	3	TB-5*25 12.9


MAGNETO



MAGNETO

Key No.	LV (+)	Part No	Description	Qty	Standard
1		A409-001320	ROTOR, MAGNETO	1	
2		A411-001840	COIL, IGNITION	1	ID#A10087
3		100142-12330	KEY, WOODRUFF	1	
4		900515-00008	NUT, FLANGE	1	8
5		V323-000070	WASHER,CIRCULAR 5	2	5.2*10*3
6		V805-000210	BOLT, TORX 5	2	TB-5*20 12.9
7		A425-000000	SPARKPLUG	1	BPMR8Y
8		A427-000013	CAP,SPARK PLUG	1	
9		A426-000010	TERMINAL,SPARKPLUG	1	


AIR CLEANER, CARBURETOR



AIR CLEANER, CARBURETOR

Key No.	LV (+)	Part No	Description	Qty	Standard
1		V103-001950	GASKET,INTAKE	1	AF74 T0.5
2		A200-001220	INSULATOR, INTAKE	1	PB-26XHD
3		V253-000990	SCREW,5	2	TB2403 12MM
4		V103-002070	GASKET,INTAKE	1	AF74 T0.5
5		A021-004930	CARBURETOR, DIAPHRAGM	1	WYG-14
6		A127-000540	COVER,DUST	1	PB-2620
7		P021-052810	CASE,CLEANER	1	
8		A244-000360	PLATE, PREVENT	1	
9		V805-000340	BOLT, TORX 5	2	TB-5*60 10.9
10		A227-000050	PLATE, ELEMENT	1	
11		A226-002030	ELEMENT, AIR FILTER	1	
12		A226-002040	ELEMENT, AIR FILTER	1	HP-70
13		P021-052800	CLEANER COVER ASY	1	
14	+	A235-000380	KNOB,CLEANER LID	2	
15		X530-000610	LABEL,EYE CATCHER	1	X-SERIES


CARBURETOR



CARBURETOR

Key No.	LV (+)	Part No	Description	Qty	Standard
1		A021-004930	CARBURETOR, DIAPHRAGM	1	WYG-14
2	+	P003-006120	BODY ASSEMBLY, PUMP	1	
3	+	123173-07930	CLIP	1	
4	+	123142-03930	COVER, M. DIAPHRAGM	1	
5	+	P003-004510	COVER, FUEL PUMP	1	
6	+	P003-005850	SWIVEL	1	
7	+	123137-19830	VALVE, INLET NEEDLE	1	
8	+	P003-004530	GASKET, FUEL PUMP	1	
9	+	123140-27230	GASKET,M. DIAPHRAGM	1	
10	+	P003-004540	DIAPHRAGM, FUEL PUMP	1	
11	+	P003-001670	DIAPHRAGM, METERING	1	
12	+	P003-005860	SCREW	1	
13	+	P003-004560	SCREW	4	
14	+	P003-004570	SCREW	4	
15	+	P003-005870	SPRING	1	
16	+	P003-001710	WASHER	2	
17	+	P003-005880	NEEDLE	1	
18	+	123126-10631	SCREEN, INLET	1	
19	+	123138-03930	PIN, METERING LEVER	1	
20	+	P003-001630	LEVER, METERING	1	
21	+	123181-09560	PUMP, PRIMER	1	
22	+	P003-006220	CLIP	1	


FUEL TANK



FUEL TANK

Key No.	LV (+)	Part No	Description	Qty	Standard
1		P100-006640	CAP,FUEL ASY	1	
2	+	V107-000190	GASKET,FUEL CAP	1	37.9*T2.2
3	+	131051-56030	CLIP, FUEL CAP	1	100L
4		132115-46730	GROMMET, FUEL	1	
5		V471-003590	PIPE	1	
6		V186-000520	JOINT,PIPE	1	
7		132010-04921	PIPE 3* 5*150	1	3*5*150
8		V490-001240	CLIP	1	
9		132010-49730	PIPE 3*6*85	1	3*6*85 YL
10		V471-005251	PIPE	1	3*5*60
11		A369-000470	STRAINER, FUEL	1	
12		V490-001240	CLIP	1	
13		A356-000031	VALVE,CHECK	1	
14		V490-001240	CLIP	1	


MUFFLER



MUFFLER

Key No.	LV (+)	Part No	Description	Qty	Standard
1		P021-052830	MUFFLER ASY	1	
2	+	A310-000510	SCREEN, ARRESTOR	1	17*41.5
3	+	V804-000030	BOLT, TORX 4	1	TB-4*8 10.9
4		V104-002350	GASKET,EXHAUST	1	T1.0
5		V805-000210	BOLT, TORX 5	2	TB-5*20 12.9


RECOIL STARTER, PULLY



RECOIL STARTER, PULLY

Key No.	LV (+)	Part No	Description	Qty	Standard
1		A127-000510	COVER,DUST	1	
2		A051-003310	STARTER,RECOIL ASY	1	
3	+	P022-048990	STATER CASE	1	
4	++	P022-045770	GUIDE, ROPE	1	
5	+	P022-049000	REEL	1	
6	+	P022-019680	SPRING, SPIRAL	1	
7	+	177236-44330	SCREW	1	
8	+	P022-049010	ROPE,STARTER	1	
9	+	P022-036700	GRIP, STARTER	1	
10		A052-000520	PULLEY,ASM STARTER	1	
11	+	A514-000120	RACHET	1	
12	+	177234-40630	SPRING, RETURN	1	
13	+	P022-002100	E-RING	1	4
14		V306-000620	WASHER,CIRCULAR 8	1	PB-26XHD
15		900502-00008	NUT 8 (3N)	1	3N8
16		V805-000150	BOLT, TORX 5	3	TB-5*16 10.9
17		X547-003480	LABEL,ECHO	1	ECHO+PB-2620


FAN CASE



FAN CASE

Key No.	LV (+)	Part No	Description	Qty	Standard
1		E103-001540	CASE,FAN	1	E-SIDE,W/TANK
2		V805-000150	BOLT, TORX 5	4	TB-5*16 10.9
3		E100-000290	FAN,BLOWER	1	
4		V806-000010	BOLT, TORX 6	2	TB-6*20 10.9
5		E103-001470	CASE,FAN	1	
6		E104-000270	GRID, BLOWER	1	
7		V805-000010	BOLT, TORX 5	7	TT-5*20 DG 10.9
8		C041-000810	HANDLE,ASM REAR	1	PB-26XHD
9		V263-000530	NUT,5	2	8*12*T4 M5
10		V353-000750	COLLAR,5	2	
11		V805-000160	BOLT, TORX 5	2	TB-5*20 10.9
12		C688-000070	WEIGHT	1	PB-26XHD
13		X505-010760	LABEL,CAUTION	1	ISO SYMBOL PB


THROTTLE



THROTTLE

Key No.	LV (+)	Part No	Description	Qty	Standard
1		P021-052770	SWITCH,ON OFF	1	
2		C450-001050	CONTROL, THROTTLE	1	
3		V430-005240	CABLE,BOWDEN	1	
4		C480-000220	GUIDE, CABLE	1	
5		V805-000240	BOLT, TORX 5	1	TT-5*12 DG 10.9
6		C453-000300	LEVER,THROTTLE	1	
7		900603-00005	WASHER	1	5
8		V805-000220	BOLT, TORX 5	1	TB-5*25 12.9
9		900605-00005	WASHER, SPRING	1	5
10		900602-00005	WASHER	1	5
11		900562-50005	NUT, LOCK	1	5


PIPE



PIPE

Key No.	LV (+)	Part No	Description	Qty	Standard
1		E165-000951	PIPE,BLOWER	1	S-SHAPE W/ GUARD
2		E165-001040	PIPE,BLOWER	1	
3		E165-000980	PIPE,BLOWER	1	FLAT PIPE

ACCESSORIES



ACCESSORIES

Key No.	LV (+)	Part No	Description	Qty	Standard
1		895410-06961	WRENCH, W/S-DRIVER	1	13X19 L135

NUMERICAL PARTS INDEX

Part No	Part description	Page	Part No	Part description	Page	Part No	Part description	Page
100013-35430	PIN, PISTON	2	A356-000031	VALVE,CHECK	12	P022-049000	REEL	16
100014-53630	SPACER, PISTON PIN	2	A369-000470	STRAINER, FUEL	12	P022-049010	ROPE,STARTER	16
100015-03931	CIRCLIP, PISTON PIN	2	A409-001320	ROTOR, MAGNETO	6	P100-006640	CAP,FUEL ASY	12
100142-12330	KEY, WOODRUFF	6	A411-001840	COIL, IGNITION	6	V100-000860	GASKET,CYL	2
100212-42031	OILSEAL	4	A425-000000	SPARKPLUG	6	V102-000300	GASKET,CRANKCASE	4
123126-10631	SCREEN, INLET	10	A426-000010	TERMINAL,SPARKPLUG	6	V103-001950	GASKET,INTAKE	8
123137-19830	VALVE, INLET NEEDLE	10	A427-000013	CAP,SPARK PLUG	6	V103-002070	GASKET,INTAKE	8
123138-03930	PIN, METERING LEVER	10	A514-000120	RACHET	16	V104-002350	GASKET,EXHAUST	14
123140-27230	GASKET,M. DIAPHRAGM	10	C041-000810	HANDLE,ASM REAR	18	V107-000190	GASKET,FUEL CAP	12
123142-03930	COVER, M. DIAPHRAGM	10	C450-001050	CONTROL, THROTTLE	20	V186-000520	JOINT,PIPE	12
123173-07930	CLIP	10	C453-000300	LEVER,THROTTLE	20	V253-000990	SCREW,5	8
123181-09560	PUMP, PRIMER	10	C480-000220	GUIDE, CABLE	20	V263-000530	NUT,5	18
131051-56030	CLIP, FUEL CAP	12	C688-000070	WEIGHT	18	V306-000620	WASHER,CIRCULAR 8	16
132010-04921	PIPE 3* 5*150	12	E100-000290	FAN,BLOWER	18	V323-000070	WASHER,CIRCULAR 5	6
132010-49730	PIPE 3*6*85	12	E103-001470	CASE,FAN	18	V353-000750	COLLAR,5	18
132115-46730	GROMMET, FUEL	12	E103-001540	CASE,FAN	18	V430-005240	CABLE,BOWDEN	20
177234-40630	SPRING, RETURN	16	E104-000270	GRID, BLOWER	18	V471-003590	PIPE	12
177236-44330	SCREW	16	E165-000951	PIPE,BLOWER	22	V471-005251	PIPE	12
895410-06961	WRENCH, W/S-DRIVER	24	E165-000980	PIPE,BLOWER	22	V490-001240	CLIP	12
900502-00008	NUT 8 (3N)	16	E165-001040	PIPE,BLOWER	22	V503-000040	SEAL,OIL 10	4
900515-00008	NUT, FLANGE	6	P003-001630	LEVER, METERING	10	V554-000020	BEARING,NEEDLE 9	2
900562-50005	NUT, LOCK	20	P003-001670	DIAPHRAGM, METERING	10	V804-000030	BOLT, TORX 4	14
900602-00005	WASHER	20	P003-001710	WASHER	10	V805-000010	BOLT, TORX 5	2
900603-00005	WASHER	20	P003-004510	COVER, FUEL PUMP	10	V805-000010	BOLT, TORX 5	18
900605-00005	WASHER, SPRING	20	P003-004530	GASKET, FUEL PUMP	10	V805-000150	BOLT, TORX 5	16
900800-36001	BEARING, BALL	4	P003-004540	DIAPHRAGM, FUEL PUMP	10	V805-000150	BOLT, TORX 5	18
900810-36000	BEARING, BALL	4	P003-004560	SCREW	10	V805-000160	BOLT, TORX 5	18
A011-001570	CRANKSHAFT,ASY	2	P003-004570	SCREW	10	V805-000210	BOLT, TORX 5	2
A021-004930	CARBURETOR, DIAPHRAGM	8	P003-005850	SWIVEL	10	V805-000210	BOLT, TORX 5	6
A021-004930	CARBURETOR, DIAPHRAGM	10	P003-005860	SCREW	10	V805-000210	BOLT, TORX 5	14
A021-004930	CARBURETOR, DIAPHRAGM	10	P003-005870	SPRING	10	V805-000220	BOLT, TORX 5	4
A051-003310	STARTER,RECOIL ASY	16	P003-005880	NEEDLE	10	V805-000220	BOLT, TORX 5	20
A052-000520	PULLEY,ASM STARTER	16	P003-006120	BODY ASSEMBLY, PUMP	10	V805-000240	BOLT, TORX 5	20
A101-000010	RING,PISTON	2	P003-006220	CLIP	10	V805-000340	BOLT, TORX 5	8
A127-000510	COVER,DUST	16	P021-052770	SWITCH,ON OFF	20	V806-000010	BOLT, TORX 6	18
A127-000540	COVER,DUST	8	P021-052780	PISTON KIT	2	X505-010760	LABEL,CAUTION	18
A130-002370	CYLINDER	2	P021-052790	CRANKCASE SET	4	X530-000610	LABEL,EYE CATCHER	8
A190-001640	COVER,ENGINE	2	P021-052800	CLEANER COVER ASY	8	X547-003480	LABEL,ECHO	16
A200-001220	INSULATOR, INTAKE	8	P021-052810	CASE,CLEANER	8			
A226-002030	ELEMENT, AIR FILTER	8	P021-052830	MUFFLER ASY	14			
A226-002040	ELEMENT, AIR FILTER	8	P022-002100	E-RING	16			
A227-000050	PLATE, ELEMENT	8	P022-019680	SPRING, SPIRAL	16			
A235-000380	KNOB,CLEANER LID	8	P022-036700	GRIP, STARTER	16			
A244-000360	PLATE, PREVENT	8	P022-045770	GUIDE, ROPE	16			
A310-000510	SCREEN, ARRESTOR	14	P022-048990	STATER CASE	16			